



## Case with Accessories for EPS044 / EPS2116 / NMS044

Refer to manual and/or video for setup instructions.

- 1 **ACC009** Monopole with 1/4-20 threaded adaptors (each end)
- 2 **CAL200** Calibrator (**may be empty!** typically only 1 sent per order unless requested)
- 3 **Microphone capsule** (e.g. 377B02)
- 4 **PRM2103-FF** or **PRM831** preamplifier
- 5 **EPS2116** base, top, and adaptor with desiccant preloaded
- 6 **Birdspike with windscreen installed**
- 7 **ADP103** adaptor to connect to TRP003
- 8 **Spare Windscreen** (refer to manual or video guide when installing on birdspike)
- 9 **CBL138** US-A to min-B cable, **CBL218** USB-A to micro-B cable, Power connector removal tool, guy wire ring for ACC009
- 10 Guy wires and stakes, Phillips #2 and #0 screwdrivers



Power connector removal tool (left) and guy wire ring (right) included along with items in 9 or 10.

