

LaserTach™ LT2

Frequently Asked Questions



Frequently Asked Questions About LaserTach™ LT2

1. How is this product different than standard tachometers, and why does it exist?	2
2. Does the LaserTach LT2 work with standard 2 mA constant current excitation?.....	3
3. Is the laser eye-safe? What is the safety rating of the laser?	3
4. Does the LaserTach LT2 digitally sample the RPM?.....	3
5. What are the advantages of having a sampled channel of tachometer data?.....	3
6. Does the LaserTach have TTL output?	3
7. What is the voltage level of the output pulse?	4
8. What is the output pulse shape?	6
9. Is this device affected by ambient light or sunlight?	7
10. How do infrared heat sources affect the LaserTach?	7
11. Can I use the LaserTach by inserting the optics into a pressurized (100 psi) environment?	8
12. Does the LaserTach operate through glass?.....	8
13. Can it be used in rain, oil, or an oil mist?.....	8
14. Will the LaserTach LT2 operate through water?.....	8
15. Will it detect the contrast between black and white strips of paper, or a paint pen?	8
16. What's the difference between reflective surfaces and retroreflective surfaces?	8
17. Where can I get retroreflective tape?.....	9
18. What are the temperature limits of the LaserTach?.....	9
19. Why does the LaserTach have an upper frequency limit?.....	10
20. What is the minimum frequency of the LaserTach?	10
21. What is the minimum distance from the LaserTach to the target for successful operation?	10
22. What is the maximum distance from the LaserTach to the target for successful operation?	10
23. Why doesn't the LaserTach LT2 work at greater distances?.....	11
24. Can I adjust the focus on the LaserTach LT2 to improve performance?.....	11
25. What is the maximum angle of incidence for successful operation of the LaserTach LT2?	11
26. Can the LaserTach LT2 be used to measure torsional vibration?	11
27. Can I use multiple tape stripes on my shaft for multiple pulses per revolution?.....	12
28. What is the minimum / maximum circumference of the shaft that must be reflecting the laser? ...	12

1. How is this product different than standard tachometers, and why does it exist?

The LaserTach LT2 is a unique offering that combines a common measurement (rotational speed) with a standardized measurement interface (ICP^{®1} sensors). Dynamic signal analyzers have long leveraged the fact that they could measure dynamic phenomena such as force, pressure, acceleration, and strain with a 2-wire constant current excitation type sensors (a.k.a. ICP or IEPE sensors). This standardization allows simplified cabling and a lower cost measurement channel. The traditional tachometer measurement contrasts this situation by requiring a (non-standardized) array of power supply requirements and multi-wire cabling.

2. Does the LaserTach LT2 work with standard 2 mA constant current excitation?

Yes, the LaserTach LT2 uses the latest in LASER technology to operate down to the 2 mA minimum of the ICP standard.

3. Is the laser eye-safe? What is the safety rating of the laser?

The LaserTach LT2 is a Class 2 device. While considered safe, users should avoid looking into the device. The strength of the beam is similar to that of a handheld laser pointer.

4. Does the LaserTach LT2 digitally sample the RPM?

No, the LASER operates continuously. The upper RPM limit is a consequence of needing to periodically sample the ambient light conditions to adapt to changes in lighting levels.

5. What are the advantages of having a sampled channel of tachometer data?

The Modal Shop recognizes the need of our customers to reference the spectral content of dynamic measurements to shaft speed. By offering the LaserTach, TMS has opened the concept of simplified cabling to those ICP sensor users that need a tachometer signal. In addition to that, acquiring rotational speed data on a sampled FFT data channel offers several advantages:

- Speed referencing to ICP tachometer signals is supported in many popular application software packages
- ICP tachometer signals enable multi tachometer applications that are not feasible using dedicated counter-timer channels
- ICP tachometer signals allow the unwrapping of phase during post processing. Phase matching in post processing must be performed on speed data that has been acquired with the same anti-aliasing filters as other measurement channels
- The time history of the pulse train can be viewed at a later date

6. Does the LaserTach have TTL output?

No. The output voltage of the LaserTach LT2 drops a minimum of 0.3 Vpp upon detection (See Question 8) of reflected 680 nm light that surpasses the detection threshold. The level returns to

¹ ICP is a registered trademark of PCB Group

bias voltage otherwise. The amplitude of the bias and voltage drop will vary based on the ICP constant current supply.

7. What is the voltage level of the output pulse?

The output voltage level of the LaserTach LT2 generally drops more with increased constant current supply.

Figures 1a and 1b show the typical output levels with a 5 ft (1.52 m) length of coaxial cable. The AC response is typically of most interest because it represents the amplitude change for a rotating shaft into an AC coupled data acquisition channel. The DC Bias Point response is what would be measured with a volt meter or DC coupled input.




Figure 1a - LaserTach Output Voltage Drop with Change in ICP Current




Figure 1b - LaserTach Output Voltage Drop with Change in ICP Current

8. What is the output pulse shape?

The amplitude of this voltage drop will vary based on the ICP constant current supply to the LaserTach LT2 (See Question 7).

Figure 2 shows a time history of LaserTach output voltage. In this case, the reflective surface was a small (<10%) portion of the overall shaft circumference. The pulse train looks like a series of blips. This is a 265 RPM wave form with an AC coupled data acquisition system. The capacitive charge and discharge portions of the waveform is coming primarily from the data acquisition AC coupling.




Figure 2 – LaserTach Pulse Train With Small Reflective Surface Coverage and 265 RPM

Figure 3 shows a LaserTach LT2 pulse train when targeted at a shaft with over 30% reflective surface coverage and 30,000 RPM. This waveform begins to approximate a square wave. Both Figure 2 and Figure 3 show rippling of the output at the voltage transition points, which is typical 'ringing' of anti-alias filters when the data is acquired on a sampled FFT analyzer channel.




Figure 3 - LaserTach Pulse Train With High Reflective Surface Coverage and 30,000 RPM

9. Is this device affected by ambient light or sunlight?

The LaserTach LT2 detects the change in reflected light of 680 nm wavelength. The LaserTach LT2 incorporates an optical bandpass filter lens cap so it is generally immune to the affects of ambient light and sunlight.



10. How do infrared heat sources affect the LaserTach?

The LaserTach LT2 incorporates an optical band pass filter and it is generally not sensitive to infrared heat sources.

11. Can I use the LaserTach by inserting the optics into a pressurized (100 psi) environment?

The LaserTach LT2 is not designed for use in environments above atmospheric pressure. Subjecting the LaserTach LT2 to significant differential pressures by threading it into the wall of a pressurized vessel will result in catastrophic failure of the device and possibly explosive disassembly.

12. Does the LaserTach operate through glass?

Yes, although any opacity in the glass will reduce the operating range.

13. Can it be used in rain, oil, or an oil mist?

Rain usually doesn't affect the performance of the LaserTach LT2 unless the relative humidity causes moisture to condense in the optics. The LaserTach LT2 is an optical sensor, so visibility through the sensing medium directly affects the performance.

14. Will the LaserTach LT2 operate through water?

The LaserTach LT2 is an optical sensor that detects changes in the intensity of reflected light of 680 nm wavelength. The transparency of any liquid through which the LaserTach is detecting this reflected light will affect the performance. Pure water will work better than water with contaminants. Any wave field that exists in the water will certainly distort the light detected on the optic sensor, and could reduce performance, or make measurements impossible. Any refraction of the reflected light will also reduce the capabilities of the LaserTach LT2 (This will be most noticeable when holding the LaserTach at an angle away from the normal to the water's surface).

Warning: *The LaserTach LT2 is not designed to be submersed in any liquid. Pointing the LaserTach through a glass or clear plastic porthole or sightglass is a good way to measure through liquid media.*

15. Will it detect the contrast between black and white strips of paper, or a paint pen?

The LaserTach LT2 operates using the limited power budget offered to ICP circuits. For this reason, the LaserTach LT2 requires retroreflective tape for best results. The use of contrasting colored surfaces dramatically reduces the operating range of the LaserTach. In a test case, the LaserTach LT2 detected a target created on a laser printer from a maximum of 3-1/2 in (8.9 cm). The target was printed on color copy paper with a brilliance rating of 96.

16. What's the difference between reflective surfaces and retroreflective surfaces?

Reflective surfaces are designed to reflect light away from the surface at an angle equal to the angle at which it hits the surface. Reaching back to our freshman physics book reveals that classic relationship 'the angle of incidence equals the angle of reflection', which is plotted in Figure 4. A reflective surface will reflect light directly back to the source only when the source is 90°, or normal, to the surface.

Figure 5 illustrates the behavior of a retro reflective surface, reflecting light directly back to the source, regardless of the angle of incidence.




Figure 4 – Reflection: Angle of incidence equals angle of reflection




Figure 5 - Retro reflection: The performance of the LaserTach LT2 is greatly enhanced when using retro reflective tape

17. Where can I get retroreflective tape?

3M Corporation markets retroreflective materials under its Scotchlite™ brand. The Modal Shop also offers Model LT-Tape, which is retroreflective.

18. What are the temperature limits of the LaserTach?

The LaserTach has operating temperature range of 14F to 122F (-10C to 50C). The temperature range for storage is -40F to 185F (-40C to 85C).

19. Why does the LaserTach have an upper frequency limit?

This is a limitation that can be traced back to the limited power budget of ICP constant current powered devices at the minimum 2mA level. The LaserTach LT2 needs to periodically sample the ambient light conditions to dynamically adjust the reflected light comparison threshold.

20. What is the minimum frequency of the LaserTach?

The LaserTach LT2 is a DC coupled device. The LaserTach LT2 is capable of detecting 0 Hz, steady state changes in reflected light. However, since it is by definition attached to an ICP sensor signal conditioner, the signal will most likely be AC coupled by the signal conditioner circuitry. This makes the low frequency limit of the LaserTach equal to the low frequency cutoff of the signal conditioner AC coupling circuitry.

There do exist DC coupled ICP signal conditioners but they are not common. Certain DC voltage tachometer channels may support the LT2 voltage levels.

21. What is the minimum distance from the LaserTach to the target for successful operation?

It depends. We don't recommend positioning the LaserTach closer than 2 in (5 cm) from the target to detect the reflected laser light.

22. What is the maximum distance from the LaserTach to the target for successful operation?

The maximum distance varies based on the ICP current level and lighting conditions. Each LaserTach LT2 is tested to ensure at least 20" (51cm) at 2mA. Under some conditions, the range can be farther. Increasing ICP current to 3.5mA or greater will maximize the range.

This is with the LaserTach LT2 positioned on the normal to the mounting surface of a retro reflective target. Introducing an angle to the mounting surface reduces the operating range. Typical data is shown in Figure 6.




Figure 6 – Typical Operating Envelope For LaserTach

23. Why doesn't the LaserTach LT2 work at greater distances?

This is a limitation of the energy supplied to the Class 2 laser from the ICP sensor signal conditioner.

24. Can I adjust the focus on the LaserTach LT2 to improve performance?

No. Do not adjust the slotted cap of the laser. The units are focused during acceptance test at the manufacturer. Adjusting this piece may reduce performance of the LaserTach or damage the laser itself, and voids warranty.

25. What is the maximum angle of incidence (See Question 16) for successful operation of the LaserTach LT2?

We have successfully tested operated the LaserTach LT2 at angles of incidence of up to 60° when using retro reflective tape.

26. Can the LaserTach LT2 be used to measure torsional vibration?

Although torsional vibration analysis is not the primary application for the LaserTach LT2, it has been successfully used in some circumstances. The utility of the LaserTach LT2 for torsional measurements is still being evaluated. It will depend on the maximum rotation rate of interest and the number of pulses per rotation below the maximum RPM of the LaserTach LT2.

While the LaserTach LT2 is low jitter, most ICP inputs on DAQ systems are sampled at a fixed rate and that rate of sampling has an inverse relationship to RPM measurement accuracy.

Figure 7 shows an RPM measurement jitter analysis for a 25,600 samples / second (10kHz Fmax) data acquisition system. The jitter is lower for higher sample rates and higher for lower sample rates.




Figure 7 : DAQ RPM Measurement Error

27. Can I use multiple tape stripes on my shaft for multiple pulses per revolution?

Yes, although you should be aware that that the frequency content of the signal will depend upon the accurate spacing of the stripes. Also keep in mind that maximum RPM effectively becomes the number of stripes times the shaft RPM.

28. What is the minimum / maximum circumference of the shaft that must be reflecting the laser?

Between 1% and 10% of the shaft circumference is usually optimum. The LaserTach LT2 continuously scans so it can detect reflections smaller than is physically practical to place on the shaft.

A limiting factor is the sample rate of the DAQ system interfaced to the LaserTach LT2. The reflective region must be wide enough to consistently be sampled each rotation.

The following equation will provide the minimum percentage that needs covered for a given RPM, Sample Rate, and number of samples.

$$\% \text{ Covered} = (\text{Number_of_Samples} * \text{RPM}) / (60 * \text{Sample_Rate})$$

Where,

Number_Of_Samples is the number of samples to capture to ensure accurate triggering and pulse detection. 10 is a good rule of thumb.

RPM is the maximum shaft rotation rate to measure

Sample_Rate is the number of samples per second. This is the actual sample rate and not the Fmax or measurement bandwidth.

For example, a 10,000RPM rotation with a sample rate of 25,600 (often an Fmax of 10,000 Hz) and 10 samples.

$$(10 \text{ Samples} * 10,000 \text{ RPM}) / (60 \text{ cycles} * 25,600 \text{ Samples}) = 6.5\%$$